



## LA SPAZIALE S40 SUPREMA - DEMONSTRATION MODE

The La Spaziale Suprema S40 has a demonstration mode.

This means that the machine will light up, appearing as though it is on, but the boiler of the machine will not heat up and none of the machine buttons will work.

### **For machines manufactured before 2016:**

This is accessed through holding down the hot water button whilst switching the machine on.

To exit this, switch the machine off at the front switch. Hold down the hot water button. Whilst holding down this hot water button, switch the machine back on using the front switch.

### **For machines manufactured after 2016:**

With the machine on, press and hold both the “+” and “-” buttons simultaneously for 15 seconds. When the display shows the probe calibration value, press the “P” button for 10 seconds. Once in DEMO mode, to return to working mode press and hold the “P” button for 15 seconds.